

INSTALLATION MANUAL

GALLIANO MRDH / MR16

- MRDH
- MRDH 1

INSTALLATION NOTICE

 **Warning**


- Please follow all the installation manual carefully. Any improper installation will cause burn, electrical shock and lamp malfunction.
- Please do not modify or change the actual part of the lamp
- Please ensure the incoming supply voltage in valid rating.
- If the lamp malfunction, please cut off the supply and call the qualified technician or the related store which sell this product.
- Please do not close this product with sound or heat prove material. 
- Please do not install this product near to the inflammable material.

 **Notice**



- Please do not install this product under direct sun reflected area, enclose with vaporized material & vibrating area.
- Please cut off the supply during the maintenance work.



Step 1: Remove the cover from lamp frame



Step 2: Connect the supply cable to the terminal block on the chassis.
 Note : Make sure that the cables "L", "N" and earth are accurately connected.



Step 4: Press both the springs on the lamp frame before inserting it into the ceiling slot.



Step 5: 3. Insert the lamp frame into ceiling hole (Refer to the catalog for the ceiling slot dimension). Make sure that the spring is placed at the upper side of the ceiling. Mount the lamp frame properly.



Step 6: Slot lamp to the lamp holder. Then, attach the cover to the lamp frame by pressing.

Lamp Changing Methods



Step 1: Remove the cover by rotating it in the anti-clockwise direction.

Step 2: Pull the lamp after placing the sucker on its surface.

Step 3: Fix the new lamp by reprising the Step 6 from the installation section

Step 3: Connect the lamp cable from the chassis to the terminal block on the lamp frame.